

MagicEzy

HAIRLINE

FIX

HOW TO APPLY



STEP 1 : PREPARE

- Do not use below 10°C / 50°F
- Suitable for above the waterline use.
- Scrape a pin point along crack to remove grime and dirt.
- Wash/scrub soapy water into damage, then rinse with clean water. Allow to fully dry in sun or accelerate dry with a hairdryer.
- Rotate/shake the tube for 30 seconds for even consistency.

STEP 2 : APPLY

- For plastic or aluminum surfaces, apply a thin coat of MagicEzy MegaFusion Primer/Sealant and allow 2 hours to cure (at 70°F/20° C).
- APPLY 2 Drops into the crack, whilst holding a tissue in your spare hand.

REPAIR SECRETS

Color match ?

Mix two or more colors on a clear plastic wrap. View new color when placed over the surface.

How do I apply on vertical surfaces ?

To prevent slump or for a FAST dry time, use a hairdryer for 3 minutes to form a skin.

STEP 3 : LEVEL

- Rapidly wipe the 'LEVEL' across the repair 5 times. FAST wipes help Hairline Fix penetrate deeply inside the damage.
- Clean the 'LEVEL' with the tissue and TRIM off surface smears.
- Some deep cracks may require several coats to fill completely. Allow at least 2 hours in between coats before re-applying (overnight is best).

How do I apply in hot / cold weather?

In temperatures above 90°F (30°C) lay a damp towel over the area until hand temperature is reached. Below 60°F /15°C, set with hairdryer for 3 minutes.

STEP 4 : TRIM

- TRIM to remove smears off the repair edge (but not the repair itself). Dampen or use a tissue to help clean-up if necessary.



NOTES :

- DRYING time varies depending on temperature. FAST DRY using a hot hair dryer for 3 minutes + 30minutes cool down. NORMAL DRY: 2 hours (at 70°F/20° C). It will harden overnight and achieve maximum strength and adhesion after 14 days.



Zi du Capitou - 85 Avenue Louis Lépine - 83600 Fréjus - FRANCE
Tel: +33 (0)4 94 53 27 70 - Fax: +33 (0)4 94 53 27 62
Info@seaviewprogress.com - www.seaviewprogress.com